


NOTES:

1-"X" CONTACTS TO MAKE FIRST AND BREAK LAST.

2-IF BELLS OF BIASED RINGER TAP WHEN DIALING FROM ANOTHER TELEPHONE ON THE LINE, REVERSE RINGER CONNECTIONS AT TERMINALS 15 AND 16.

3-IF NO DIAL IS USED, CONNECT BL AND YEL DIAL WIRES TO TERMINAL 2; WH TO TERMINAL 3 AND RED TO TERMINAL 4 OF DIAL BLANK.

4-WITH STANDARD DIAL, WIRING AT TERMINAL BLOCK SHOWN FOR METALLIC (BRIDGED) RINGING.
FOR GROUND (DIVIDED) RINGING:
L1 (-RING) TO GRD - MOVE YEL LINE CORD LEAD AT TERMINAL BLOCK FROM TERMINAL L2 TO TERMINAL 4G.
L2(+TIP) TO GRD - MOVE YEL LINE CORD LEAD AT TERMINAL BLOCK FROM TERMINAL L2 TO TERMINAL 4G. AND REVERSE TIP AND RING LEADS OF INTERIOR WIRING


5-WITH SATT DIAL:
L1(-RING) TO GRD - MOVE YEL LINE CORD LEAD AT TERMINAL BLOCK FROM TERMINAL L2 TO TERMINAL 4G.

L2(+TIP) TO GRD - MOVE YEL LINE CORD LEAD AT TERMINAL BLOCK FROM TERMINAL L2 TO TERMINAL 4G. MOVE RED RINGER LEAD FROM TERMINAL 15 TO TERMINAL 7.

METALLIC (BRIDGED) RINGING - MOVE YEL LINE CORD LEAD AT TERMINAL BLOCK FROM TERMINAL L2 TO TERMINAL 4G; MOVE BLK CAPACITOR LEAD FROM TERMINAL 9 TO TERMINAL 7.

DO NOT REVERSE LINE LEADS - POLARITY OF LINE MUST BE MAINTAINED AS SHOWN.

6-TO CONVERT TO HOOKLATCH:
A-MOVE OR CRADLESWITCH WIRE FROM TERMINAL 6 TO TERMINAL 1.
B-MOVE YEL DIAL WIRE FROM TERMINAL 11 TO TERMINAL 6.
C-MOVE BLK. CRADLESWITCH WIRE FROM TERMINAL 10 TO TERMINAL 6.
D-REMOVE GR CRADLESWITCH WIRE FROM TERMINAL 13 AND TAPE.
E-STRAP TERMINAL 10 AND TERMINAL 11.
F-MOVE RED CRADLESWITCH WIRE FROM TERMINAL 2 TO TERMINAL 8.
G-MOVE WH CRADLESWITCH WIRE FROM TERMINAL 8 TO TERMINAL 2.



Schematic and Wiring Diagram, Type 80 Self-Compensating Telephone Set (NB-802 Series) with Potted Transmission Unit.