



Fig. 5—Installation of Mounting Cord Using D-180778 Kit of Parts

(Candlestick Type)

Convert customer's candlestick housing as follows.

Remove four mounting screws which secure baseplate to candlestick housing.

Remove dial bracket retaining screw from designated hole in baseplate.

Remove dial mounting plate and remove dummy dial by removing two screws.

Follow 3.11 for 6-type dial installation procedures.

Remove dummy handset cord from base.

Follow 3.15 for handset cord installation procedures.

When disassembling transmitter housing, remove the horn. When reassembling, make sure nut at pivot point is properly

3.12 Install 581A Telephone Set Base as follows.

- (1) Remove line switch from 581A base (current model only).
- (2) Remove square snap-in cover from bottom of candlestick mounting base.
- (3) Mount line switch to customer's set with actuator toward terminal board.
- (4) A typical installation of a candlestick type telephone set is shown in Fig. 6.
- (5) If 581A base (subset) is wall mounted, adjust ringer volume control to "LOUD" before attaching subset to wall.



When 581A base is mounted on a wall or other vertical surface, the base should be flush against surface for proper operation of P1A ringer.

- (6) See 3.14 for mounting cord installation procedures.