



NOTES:

1. CONNECT RINGER LEAD TO TERM. 10 FOR METALLIC RINGING, OR TO TERM. 12 FOR GROUNDED RINGING.
2. WHEN DIAL IS USED CONNECT RED LINE CORD TO TERM. 2, OTHERWISE TO TERM. 3.
3. CONNECT NEON LAMP (OR GAS TUBE) WHEN USED, TO TERM. 1 AND 5, OR 333 A TUBE TO TERM. 1, 5 AND 12; OTHERWISE CONNECT GREEN CONDENSER LEADS TO TERM. 1 AND 5.

DESK & WALL TELEPHONE 601-605

LEICH ELECTRIC CO.

C-4917-B

12281